



Getting the most from your Wahl Clippers!

Oiling Your Wahl Clipper


Wahl Clippers should be oiled on a regular basis as part of the ongoing maintenance of your clipper. Oiling is a quick and easy way to ensure better cutting performance and longer blade life. As the top blade of the clipper moves at very high speed it is essential oil is present to stop both heat and wear. Simply turn on the clipper and apply two or three drops of oil across the top of the moving blade. This procedure should be done prior to every haircut to give you the best possible performance.

Use only WAHL CLIPPER OIL as it is specifically designed for this role and will not leave any sticky residue on the blades.

Tuning Your Wahl Clipper

Wahl Clippers are tuned at the factory to run on Australian or New Zealand voltage (230~240v/50Hz) however due to the nature of our electrical supply system means the actual voltage in your location can be +/- 10%. Clipper performance will vary with the actual voltage in your location, so it is essential TO TUNE your clipper to get the best performance. The procedure for this is as follows:

1. Oil your clipper as instructed above.
2. With the clipper still running, turn the power screw (the large plastic screw on the side on the Clipper - see diagram below) clockwise until you hear a loud 'clattering' noise.
3. Now turn the screw anti-clockwise about 1/2 a turn, until the clattering stops.
4. Turn the clipper on and off a few times to make sure it does not clatter. If it continues to clatter turn the screw a little further anti-clockwise.



A 5 cent piece is ideal for adjusting the power screw.


Removing Your Wahl Clipper Blades

Your Clipper blades should be removed periodically (at least once a month) to allow the cut hair to be cleaned out from under the blades. Simply use a Philips head screwdriver to undo the blade screws and then remove the blades. Remove the sponge and clean it plus any hair that is caught in the clipper. Reverse the process to re-attach the blades.

Aligning Your Wahl Clipper Blades

Wahl Clippers have adjustable blade alignment which needs to be reset after removing the blades or tuning your clipper, as this will affect the blade alignment. With the blade screws only semi tightened, you can move the bottom blade around to position it correctly as below:

1. Move the taper level upwards towards the lid of the clipper so the blades are in the closed position i.e. closest cutting length.
2. The top & bottom blades should be parallel with the top blade approx 0.8mm behind the bottom blade. (Do not have the top blade level with the bottom blade as this can cause skin pinching or cutting). See Diagram Below.
3. The extreme left hand tooth on the top blade should be positioned so it is over the gap between the two left hand teeth of the lower blade. i.e. the extreme left gap on the lower blade. See Diagram Below.
4. Slowly tighten each screw ensuring you do not alter the alignment in the process. The best way is to tighten each screw a little at a time swapping from one to the other.
5. Check your alignment setting with the blades tightened and the lever in the closed position to ensure you do not cause pinching or cutting of the skin.



WAHL®

The Brand used by Professional Hairdressers